


# Quick Start Guide



-  Power On/Off
-  Peak Hold On/Off / Reset
-  Weight Units  
*Tonne > Kilonewtons  
> Kilogrammes > Pounds*
-  Tare

## AVAILABLE KEYS

### BACKLIGHT ON



### PAIRING TO A LOAD CELL

(If purchased separately)



### TO END PAIRING



### INDIVIDUAL > SUM TOTAL



If more than one load cell is being used, use the keys to switch from individual to total.

### CONFIGURATION MENU



SCROLL UP



SCROLL DOWN



ENTER

### FULL SW-HHP MANUAL DOWNLOAD



# SW-HHP

v1.00  
Part No:  
SU6060